

FREEZE DRYING

The best technology for the food conservation



Aroma, flavor and nutritional value for much more time

FREEZE DRYING








Today, more than ever, consumer requires food products with a longer shelf life compared to fresh produce, but maintaining all its nutritional properties, color, fragrance and taste. When we dehydrate a product by freeze drying, all these properties are maintained, because products are first frozen and then dehydrated at high vacuum levels, thus removing just water and leaving the product intact.

The lyophilization process basically involves four stages:

- 1. Freeze the food.
- 2. Apply a vacuum.
- 3. The ice sublimes in steam and this is extracted from the drying chamber.
- 4. Once this process is complete, removes the food from the lyophilizer and is ready to be packed and stored.

MAIN APPLICATIONS:

- · Coffee, tea and other extracts and liquids
- Vegetables, fruits
- Meat and seafood
- Prepared meals
- Milk products
- Dyes, pharmaceuticals, pigments





BENEFITS:

- The product keeps for as long as possible the original color, flavor and nutrients.
- Instant rehydration. a
- Lightweight for easy handling and transport.
- No need for refrigeration during transport and storage.
- Long shelf life due to the elimination of 95% -99.5% of water.
- Little loss of activity of the ingredients.
- Small decrease in the volatile chemicals, nutrients and heat sensitive components.
- With minimal changes in properties, since the effect of the growth of microorganisms and enzymes can not be performed at low temperatures.





CIMA, your best ally in food preservation

ADVANTAGES

- Automatic process
- Touchscreen
- CFR21 part 11 (optional)
- Scada System
- Each of our models possesses a peripheral freezing chamber (optional), implemented to pass of a process for batches to a semi continuous process, reducing the process times and production cost.

CIMA has the capacity to develop your Project from the idea, through installation and startup to technology transfer.



TECHNICAL SPECIFICATIONS

ltem	Unit	TFDS-1	TFDS-3	TFDS-5	TFDS-10	TFDS-20	TFDS-30	TFDS-50	TFDS-75	TFDS-100	TFDS-150	TFDS-200
Effective Drying Area	m²	1.1	3.15	5.12	10.48	19.88	31.68	51.48	79.2	102	147.84	204
Ice Capacity	Kg	12	36	60	120	240	360	600	900	1,200	1,800	2,400
Power Requeriment	KW.H	12	18	21	35	45	65	125	150	190	230	275
Freeze drying chamber dimensions (L*W)	m	2.23*1	2.5*1.1	3*1.2	5.4*1.4	6.1*4	8*5.2	10*5.5	11*9.5	11.5*10	15*6	19*6
Input Capacity @10% solids	kg/ batches	10	30	50	100	200	300	500	750	1000	1500	2000
Output Capacity	kg/ batches	1	3	5	10	20	30	50	75	100	150	200

 $[*]Information only for {\it reference}. The {\it production capacity depends on the product proprieties}.$





PANAMÁ

World Trade Center. 1er Piso, Área Comercial. Calle 53 Marbella. Apartado 0832-00155 WTC Panamá, República de Panamá. Tel. +507-205-1915 Fax. +507-205-1802

CIUDAD DE MÉXICO, MÉXICO.

Pafnuncio Padilla 26 Piso 3, Despacho 329 Ciudad Satélite, Naucalpan de Juárez, Estado de México. C.P. 53100 Tel. +52-55-2455-5901

COLOMBIA

Calle 100 # 8ª-55 Torre C Oficina 1005. Bogotá, Colombia. Tel : +57-1-6567381

ECHADO

Calle los Senderos No. C 9 Las Cascadas Pichincha, Quito Ecuador.

ARGENTINA

Fragata Trinidad 1539 Ciudad Autónoma de Buenos Aires CP 1440. República Argentina. Tel. + 54 11 4686 3868

GUADALAJARA, MÉXICO

Av. Doctor Roberto Michel 1156 Col. San Carlos. Guadalajara, Jalisco, México. C.P. 44460 Tel. +52-33-4777-6000

BRASIL

Gessy Lever, 869 Lenheiro, Valinhos 13.272-000 São Paulo, Brasil.

Madrid #245, Departamento #501, Miraflores, Lima-Perú.

PERÚ

SHANGHAI

Office 301, Builiding 12, Lane 2328 Chun Sheng Minhang District C.P. 201100 Shanghai, People's Republic of China. Tel. +86-21-54993845 Fax. +86-21-54992467

VENEZUELA

Av. Francisco de Miranda, Centro Seguros La Paz, Piso 8, Ala Oeste, Of. 360. Boleita Sur. Caracas, Venezuela. Tel: +58 212 8232336

GUATEMALA

12 Calle 1-25 Zona 10 Géminis Diez Torre Norte Oficina 1203, Ciudad de Guatemala, Guatemala.

ECUADOR

Alcántara 200 piso 6 Las Condes Santiago de Chile, Chile.

CHILE

COSTA RICA

Itskatzú, Suite 203, 2do Piso. Escazú, San José, Costa Rica.

USA

256 Airport Road Fall River, MA 02720, USA.

EGIPTO

11Emad El Din Calle Egipto.